

t47 external spacer overview



hollowtech II + sram gxp* overview

	bottom bracket housing width (in mm)	derailleur type	outer spacer non-drive-side (in mm)	inner spacer non-drive-side (in mm)	inner spacer drive-side (in mm)	outer spacer drive-side (in mm)
mtb	73	no front Derailleur	/	0	2.5	/
	73	Clamp/Solder	/	0	2.5	/
	73	E-Type	/	0	0 + E-Type	/
mtb	68	no front Derailleur	/	2.5	5	/
	68	Clamp/Solder	/	2.5	5	/
	68	E-Type	/	2.5	/	/
road gravel	68 road	Clamp/Solder	0.65	0	0	0.65
	/	/	/	/	/	/

*for sram gxp cranksets use the supplied gxp-adapter-kit.

If spacers are supplied with your shimano crankset, these must be installed with the crankset according to the manufacturer's instructions.

sram dub overview

	bottom bracket housing width (in mm)	crankset	outer spacer non-drive-side (in mm)	inner spacer non-drive-side (in mm)	inner spacer drive-side (in mm)	outer spacer drive-side (in mm)
mtb	68	MTB	/	2.5	2.5	4.5
	68	MTB wide	3	2.5	2.5	7.5
	73	MTB	/	/	/	4.5
	73	MTB wide	3	/	/	7.5
	73	Superboost +	4.5	/	/	9
	73 ai	MTB ai	2.5	2.5	/	10.5
	73 with chain guide	MTB	/	/	Chain guide	2
	73 with chain guide	MTB wide	3	/	Chain guide	5
	73 with chain guide	Superboost +	4.5	/	Chain guide	6.5
road	68	RD	/	/	/	3
	68	RD-wide	2.5	/	/	5.5
	73	RD-wide	/	/	/	3